


How to configure RTMP out for TBS2605 HDMI Encoder

The following will explain you how to configure TBS2605 RTMP to push your stream to CDN, Media Server or sharing sites.

Before go to configure RTMP push, please make sure your Encoder “stream---push” option is selected to “on”, like this:



1.RTMP Server with “url” type:

Just put the RTMP Server url to Encoder “push url”. For example, `rtmp://localhost:1935/live/streamname`

2.RTMP Server with username and password. Please refer to

`rtmp://xxx.xxx.xxx.xxx live=true pubUser=user pubPasswd=pass`

3.Sharing sites

TBS2605 also support sharing your stream to sharing site like Twitch, Youtube.

Twitch

The “push url” should be

`rtmp://live.twitch.tv/app/<stream key>`

for example,

`rtmp://live.twitch.tv/app/live_*****_*****`

Youtube


push url:`rtmp://a.rtmp.youtube.com/live2/<key>`

TBS2605 RTMP protocol is based on FFMPEG, so you can also get more examples from Internet.


Push to Xstream-Codes

1.RTMP WhiteList IP/DNS Verification:


Not everyone can Push RTMP streams to your Xstream-Codes Server. You need to allow the IPs first:



2. Check Xtream-codes Server IP and RTMP port



3. TBS2605 rtmp setting:



“push” must be selected to “on”.

“push url” content “rtmp://xtream-Codes Server IP:port/live/test0”.

Any question, please write to us:
support@tbsdtv.com